

PHOTOMULTIPLIER TUBE R10454

FEATURES

●High quantum efficiency (at 121.6 nm)

...... 26.0 % (Typ.)

●High anode sensitivity (at 121.6 nm)

...... 1.0 × 10⁵ A/W (Typ.)

 Excellent solar blind spectral response (Anode sensitivity ratio)

> 121.6 nm / 200 nm 2800 (Typ.) 121.6 nm / 250 nm 5500 (Typ.) 121.6 nm / 300 nm 8500 (Typ.)



APPLICATIONS


- •Atomic emission spectrophotometer
- Plasma emission spectrophotometer
- ●VUV-UV spectrophotometer

SPECIFICATIONS

GENERAL

P	Parameter	Description / Value	Unit		
Spectral respo	nse	115 to 195	nm		
Wavelength of	maximum response	130	nm		
Photocathode	material	Cs-I	_		
Window mater	ial	MgF ₂	_		
Minimum effect	tive area	8 × 12	mm		
Dynode	Structure	Circular-cage			
	Number of stage	9	_		
	Material	Sb-Cs	_		
Direct	Anode to dynode No.9	Approx. 4	рF		
interelectrode	Anode to	Approx. 6	nΕ		
capacitances	All other electrodes	Арргох. 6	pF		
Base		11-pin base JEDEC No. B11-88	_		
Weight		48.5	g		
Operating amb	pient temperature	-30 to +50	°C		
Storage tempe	erature	-30 to +50	°C		
Suitable socket	for base (sold separately)	E678-11A			

Figure 1: Typical spectral response



Subject to local technical requirements and regulations, availability of products included in this promotional material may vary. Please consult with our sales office. Information furnished by HAMAMATSU is believed to be reliable. However, no responsibility is assumed for possible inaccuracies or omissions. Specifications are subject to change without notice. No patent rights are granted to any of the circuits described herein. ©2024 Hamamatsu Photonics K.K.

PHOTOMULTIPLIER R10454

MAXIMUM RATINGS (Absolute maximum values)

	Parameter	Value	Unit
Supply voltage	Between anode and cathode	1250	V
	Between anode and last dynode	250	٧
	Between successive dynodes	250	V
	Between first dynode and cathode	250	V
Average anode current (A)		0.1	mA

CHARACTERISTICS (at 25 °C)

	Parameter		Value	Unit
Cathode	Radiant sensitivity at 121.6 nm	Тур.	25.5	mA/W
sensitivity	Quantum efficiency at 121.6 nm	Тур.	26	%
	Quantum efficiency at 133 nm (Peak)	Тур.	32.4	%
Anode radiant sensitivity at 121.6 nm [®]		Тур.	1.0 × 10 ⁵	A/W
Gain at 1000 V			3.9 × 10 ⁶	_
Anode dark current (After 30 min storage in darkness)			0.1	nA
ENI (Equivalent noise input) at 121.6 nm [®]			1.12 × 10 ⁻¹⁶	W
Anode pulse rise time [®]			2.2	ns
Time response	Electron transit time ®		22	ns
	Transit time spread [©]		1.2	ns
Anode	121.6 nm / 200 nm	Тур.	2800	_
sensitivity	121.6 nm / 250 nm	Typ.	5500	_
ratio	121.6 nm / 300 nm		8500	_

NOTES

- A: Averaged over any interval of 30 seconds maximum.
- B: Measured with the voltage distribution ratio shown in Table 1 below.

Table 1: Voltage distribution ratio

Electrode	K	D	y1 D	y2	Dy3	Dy	/4	Dy5	D	y 6	Dy7	Dy	8 D	у9	F)
Distribution ratio		1	1	1	1	1	1		1	1	-	1	1	1		

Supply voltage=1000 V

K: Cathode Dy: Dynode P: Anode

- ©: Measured with the same supply voltage and voltage distribution ratio as Note B after removal of light.
- ①: ENI is an indication of the photon-limited signal-to-noise ratio. It refers to the amount of light in watts to produce a signal-to-noise ratio of unity in the output of a photomultiplier tube.

$$\mathsf{ENI} = \frac{\sqrt{2q \cdot \mathsf{Idb} \cdot g \cdot \Delta f}}{\mathsf{S}}$$

where

- $q = Electronic charge (1.60 \times 10^{-19} coulomb).$
- ldb = Anode dark current (after 30 minutes storage) in amperes.
- g = Gain.
- Δf = Bandwidth of the system in hertz. 1 hertz is used.
- S = Anode radiant sensitivity in amperes per watt at the wavelength of peak response.

- E: The rise time is the time for the output pulse to rise from 10 % to 90 % of the peak amplitude when the entire photocathode is illuminated by a delta function light pulse.
- E: The electron transit time is the interval between the arrival of delta function light pulse at the entrance window of the tube and the time when the anode output reaches the peak amplitude. In measurement, the whole photocathode is illuminated.
- ⑤: Also called transit time jitter. This is the fluctuation in electron transit time between individual pulses in the signal photoelectron mode, and may be defined as the FWHM of the frequency distribution of electron transit times.



Figure 2: Typical spectral response




Figure 3: Typical gain and anode radiant sensitivity





Figure 4: Typical time response



PHOTOMULTIPLIER R10454

Figure 5: Dimensional outline and basing diagram (Unit: mm)





Figure 6: Socket E678-11A (Sold separately) (Unit: mm)



* E678-11A cannot be used in the vacuum.

NOTE: There is a 2 millimeter diameter hole to exhaust inner air on the plastic base.

Handling precautions

Operate below 10⁻¹ pascal condition or atmospheric pressure.

Warning-Personal Safety Hazards

Electrical Shock—Operating voltages applies to this device present a shock hazard.

HAMAMATSU PHOTONICS K.K. www.hamamatsu.com

Electron Tube Division

Electron Tube Division
314-5, Shimokanzo, Iwata City, Shizuoka Pref., 438-0193, Japan, Telephone: (81)539/62-5248, Fax: (81)539/62-2205
U.S.A.: HAMAMATSU COPROBATION: 360 Foothill Road, Bridgewater, NJ 08807, U.S.A., Telephone: (1)908-231-0960, Fax: (1)908-231-1218 E-mail: usa@hamamatsu.com
Germany: HAMAMATSU PHOTONICS DEUTSCHLAND GMBH.: Arzbergerstr. 10, 82211 Herrsching am Ammersee, Germany, Telephone: (49)8152-375-0, Fax: (49)8152-265-8 E-mail: info@hamamatsu.de
France: HAMAMATSU PHOTONICS FRANCE S.A.R.L.: 19 Rue du Saule Trapu, Parc du Moulin de Massy, 91888 Massy Cedex, France, Telephone: (33)1 69 53 71 00. Fax: (33)1 69 53 71 10 E-mail: info@hamamatsu.fr
United Kingdom: HAMAMATSU PHOTONICS IL LIMITED: 2 Howard Court, 10 Tewin Road, Welwyn Garden City, Hertfordshire, AL7 1BW, UK, Telephone: (49)1-707-294888, Fax: (44)107-7294888, Fax: (44)107-7294888, Fax: (49)107-7294888, Fax: (49)107-729488, Fax: (49)107-7294888, Fax: (49)107-729488, Fax: (49)107-7294888, Fax: (49)107-TPMS1073E03

JUN. 2024 IP