

InGaAs PIN photodiodes

G12183 series



Long wavelength type (cutoff wavelength: 2.55 to 2.6 μm)

Features

- Cutoff wavelength: 2.55 to 2.6 μm
- Low cost
- Photosensitive area: φ0.3 to φ3 mm
- Low noise
- High sensitivity
- High reliability
- High-speed response
- High short-wavelength sensitivity
(G12183-210KA-03): 0.4 A/W (λ=900 nm)

Applications

- Optical power meters
- Gas analysis
- Moisture meters
- NIR (near infrared) photometry

Options

- Amplifier for InGaAs PIN photodiode **C4159-03**
- Heatsink for one-stage TE-cooled type **A3179**
- Heatsink for two-stage TE-cooled type **A3179-01**
(excluding G12183-210KA-03)
- Temperature controller for TE-cooled type **C1103-04**

Structure

Type no.	Dimensional outline/ Window material*1	Package	Cooling	Photosensitive area (mm)
G12183-003K	(1)/K	TO-18	Non-cooled	φ0.3
G12183-005K				φ0.5
G12183-010K				φ1
G12183-020K	(2)/K	TO-5		φ2
G12183-030K				φ3
G12183-103K				(3)/K
G12183-105K	φ0.5			
G12183-110K	One-stage TE-cooled	φ1		
G12183-120K		φ2		
G12183-130K		φ3		
G12183-203K	(4)/K	TO-8	Two-stage TE-cooled	
G12183-205K				φ0.5
G12183-210K				φ1
G12183-220K				φ2
G12183-230K				φ3
G12183-210KA-03				(5)/K

*1: K=borosilicate glass

The G12183 series may be destroyed or deteriorated by static electricity. Use caution when handling.

➤ Absolute maximum ratings (Ta=25 °C, unless otherwise noted)

Type no.	Thermistor power dissipation Pd_th (mW)	Allowable TE-cooler current I _{TE} max (A)	Allowable TE-cooler voltage V _{TE} max (V)	Reverse voltage V _R max (V)	Operating temperature* ² T _{opr} (°C)	Storage temperature* ² T _{stg} (°C)
G12183-003K	-	-	-	-	-40 to +85	-55 to +125
G12183-005K						
G12183-010K						
G12183-020K						
G12183-030K						
G12183-103K	0.2	1.5	1.0	1	-40 to +70* ³	-55 to +85
G12183-105K						
G12183-110K						
G12183-120K						
G12183-130K						
G12183-203K		1.0	1.2	0.5		
G12183-205K						
G12183-210K						
G12183-220K						
G12183-230K						
G12183-210KA-03						

*2: No dew condensation

When there is a temperature difference between a product and the surrounding area in high humidity environments, dew condensation may occur on the product surface. Dew condensation on the product may cause deterioration in characteristics and reliability.

*3: Chip temperature and package temperature

Note: Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.


➤ Electrical and optical characteristics (Typ. unless otherwise noted)

Type no.	Measurement conditions	Thermistor resistance (+25 °C) R _{sh} (kΩ)	Thermistor B constant (-20/+25 °C) B (K)	Spectral response range λ (μm)	Peak sensitivity wavelength λ _p (μm)	Photosensitivity S λ=λ _p		Dark current I _D V _R =0.5 V		Temperature coefficient of dark current V _R =0.5 V (times/°C)
	Chip temperature T _{chip} (°C)					Min. (A/W)	Typ. (A/W)	Typ. (μA)	Max. (μA)	
G12183-003K	25	-	-	0.9 to 2.6				0.4	4	1.035
G12183-005K								1	10	
G12183-010K								3	30	
G12183-020K								10	100	
G12183-030K								30	300	
G12183-103K	-10	9.0	3300	0.9 to 2.57	2.3	1	1.3	0.12	1.2	
G12183-105K								0.3	3	
G12183-110K								0.9	9	
G12183-120K								3	30	
G12183-130K								9	90	
G12183-203K	-20	9.0	3300	0.9 to 2.55				0.085	0.85	
G12183-205K								0.21	2.1	
G12183-210K								0.65	6.5	
G12183-220K								2.1	21	
G12183-230K								6	60	
G12183-210KA-03								0.05* ⁴	0.1* ⁴	1.067* ⁴


*4: V_R=10 mV

Type no.	Measurement conditions	Cutoff frequency fc		Terminal capacitance Ct		Shunt resistance Rsh		Detectivity D*		Noise equivalent power NEP	
	Chip temperature Tchip (°C)	VR=0 V RL=50 Ω		VR=0 V f=1 MHz		VR=10 mV		λ=λp		λ=λp	
		Min. (MHz)	Typ. (MHz)	Typ. (pF)	Max. (pF)	Min. (kΩ)	Typ. (kΩ)	Min. (cm·Hz ^{1/2} /W)	Typ. (cm·Hz ^{1/2} /W)	Typ. (W/Hz ^{1/2})	Max. (W/Hz ^{1/2})
G12183-003K	25	20	50	50	100	20	100	3 × 10 ¹⁰	9 × 10 ¹⁰	4 × 10 ⁻¹³	9 × 10 ⁻¹³
G12183-005K		5	20	140	300	10	50			5 × 10 ⁻¹³	1.5 × 10 ⁻¹²
G12183-010K		2	6	500	1000	2.8	14			1 × 10 ⁻¹²	3 × 10 ⁻¹²
G12183-020K		1	1.5	1800	3000	0.65	3			2 × 10 ⁻¹²	5 × 10 ⁻¹²
G12183-030K		0.5	0.8	4000	5000	0.25	1.4			3 × 10 ⁻¹²	8 × 10 ⁻¹²
G12183-103K	-10	20	70	44	100	200	1000	1 × 10 ¹¹	3 × 10 ¹¹	1 × 10 ⁻¹³	3 × 10 ⁻¹³
G12183-105K		5	25	120	300	100	500			1.5 × 10 ⁻¹³	4.5 × 10 ⁻¹³
G12183-110K		2	7	440	1000	28	140			2.5 × 10 ⁻¹³	8 × 10 ⁻¹³
G12183-120K		1	2	1500	3000	6.5	30			5.5 × 10 ⁻¹³	2 × 10 ⁻¹²
G12183-130K		0.5	0.9	3400	5000	2.8	14			8.5 × 10 ⁻¹³	2.5 × 10 ⁻¹²
G12183-203K	-20	20	75	40	100	400	2000	1.5 × 10 ¹¹	4.5 × 10 ¹¹	7 × 10 ⁻¹⁴	2 × 10 ⁻¹³
G12183-205K		5	28	110	300	200	1000			1 × 10 ⁻¹³	3 × 10 ⁻¹³
G12183-210K		2	8	400	1000	55	280			2 × 10 ⁻¹³	5.5 × 10 ⁻¹³
G12183-220K		1	2.3	1400	3000	13	60			4 × 10 ⁻¹³	1 × 10 ⁻¹²
G12183-230K		0.5	1	3200	5000	5.5	28			6 × 10 ⁻¹³	2 × 10 ⁻¹²
G12183-210KA-03		2	4	500	1000	100	200			2 × 10 ¹¹	4 × 10 ¹¹

Spectral response



Spectral transmittance of window material




*5: Excluding G12183-210KA-03

KIRD0491EE


KIRD0639EB

Photosensitivity temperature characteristics



KIRD80642EA


Linearity



KIRD80539EB


Dark current vs. reverse voltage

Non-cooled type



KIRD80492EB


TE-cooled type



Note: Values in parentheses indicate chip temperature.


KIRD80531EC

Terminal capacitance vs. reverse voltage



KIRDB0493EC


Shunt resistance vs. chip temperature



Note: The operating temperature for the one-stage TE-cooled type and two-stage TE-cooled type is up to 70 °C.


KIRDB0494ED

Thermistor temperature characteristics




KIRDB0116EC

Cooling characteristics of TE-cooler



KIRDB0231EA




Current vs. voltage characteristics of TE-cooler



KIRD0115EB

Dimensional outlines (unit: mm)

(1) G12183-003K/005K/010K






Distance from photosensitive area center to cap center

$$-0.2 \leq X \leq +0.2$$

$$-0.2 \leq Y \leq +0.2$$

(2) G12183-020K/030K



Distance from photosensitive area center to cap center


$$-0.2 \leq X \leq +0.2$$

$$-0.2 \leq Y \leq +0.2$$

KIRDA0220EA


KIRDA0221EA

(3) G12183-103K/105K/110K/120K/130K




KIRDA0228EA

(4) G12183-203K/205K/210K/220K/230K



KIRDA0229EA

(5) G12183-210KA-03



KIRDA0265EC

Recommended soldering conditions

Solder temperature: 260 °C (10 s or less, once)

Solder the leads at a point at least 1 mm away from the package body.

Note: When you set soldering conditions, check that problems do not occur in the product by testing out the conditions in advance.

Related information

www.hamamatsu.com/sp/ssd/doc_en.html

■ Precautions

- Disclaimer
- Safety consideration / Opto-semiconductor products
- Precautions / Compound opto-semiconductors (photosensors, light emitters)

■ Catalogs

- Selection guide / Infrared detectors
- Technical note / Compound semiconductor photosensors

Information described in this material is current as of February 2025.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.

HAMAMATSU

www.hamamatsu.com

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Chuo-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81)53-434-3311, Fax: (81)53-434-5184

U.S.A.: HAMAMATSU CORPORATION: 360 Foothill Road, Bridgewater, NJ 08807, U.S.A., Telephone: (1)908 231 0960, Fax: (1)908 231 1218

Germany: HAMAMATSU PHOTONICS DEUTSCHLAND GMBH: Arzbergerstr. 10, 82211 Herrsching am Ammersee, Germany, Telephone: (49)8152 375 0, Fax: (49)8152 265 8 E mail: info@hamamatsu.de

France: HAMAMATSU PHOTONICS FRANCE S.A.R.L.: 19 Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy Cedex, France, Telephone: (33)1 69 53 71 00, Fax: (33)1 69 53 71 10 E mail: infos@hamamatsu.fr

United Kingdom: HAMAMATSU PHOTONICS UK LIMITED: 2 Howard Court, 10 Tewin Road, Welwyn Garden City, Hertfordshire, AL7 1BW, UK, Telephone: (44)1707 294888, Fax: (44)1707 325777 E mail: info@hamamatsu.co.uk

North Europe: HAMAMATSU PHOTONICS NORDEN AB: Torshamnsgatan 35, 16440 Kista, Sweden, Telephone: (46)8 509 031 00, Fax: (46)8 509 031 01 E mail: info@hamamatsu.se

Italy: HAMAMATSU PHOTONICS ITALIA S.R.L.: Strada della Moia, 1 int. 6 20044 Arese (Milano), Italy, Telephone: (39)02 93 58 17 33, Fax: (39)02 93 58 17 41 E mail: info@hamamatsu.it

China: HAMAMATSU PHOTONICS (CHINA) CO., LTD.: 1201, Tower B, Jianning Center, 27 Dongsanhuan Beilu, Chaoyang District, 100020 Beijing, P.R. China, Telephone: (86)10 6586 6006, Fax: (86)10 6586 2866 E mail: hpc@hamamatsu.com.cn

Taiwan: HAMAMATSU PHOTONICS TAIWAN CO., LTD.: 13F 1, No.101, Section 2, Gongdao 5th Road, East Dist., Hsinchu City, 300046, Taiwan(R.O.C) Telephone: (886)3 659 0080, Fax: (886)3 659 0081 E mail: info@hamamatsu.com.tw