


Si PIN photodiode array

S14833



6-element array for encoders

The S14833 is a surface mount type 6-element Si PIN photodiode array. Each of the six elements is separated, and their arrangement is suitable for encoders.

Features

- High sensitivity
- Surface mountable chip carrier package
- Compatible with lead-free solder reflow

Applications

- Encoders

Structure

Parameter	Specification	Unit
Number of elements	6	-
Element size	2.76 × 1.37	mm
Package	Glass epoxy	-
Window material	Silicone resin	-

Absolute maximum ratings (Ta=25 °C)

Parameter	Symbol	Value	Unit
Reverse voltage	VR max	30	V
Operating temperature*1	Topr	-40 to +100	°C
Storage temperature*1	Tstg	-40 to +125	°C
Soldering temperature	Tsol	260 (3 times)*2	°C

*1: No dew condensation.

When there is a temperature difference between a product and the surrounding area in high humidity environments, dew condensation may occur on the product surface. Dew condensation on the product may cause deterioration in characteristics and reliability.


*2: Reflow soldering, JEDEC J-STD-020 MSL 3, See P.5

Note: Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.


Electrical and optical characteristics (Ta=25 °C, per element)

Parameter	Symbol	Condition	Min.	Typ.	Max.	Unit
Spectral response range	λ		-	340 to 1100	-	nm
Peak sensitivity wavelength	λ_p		-	960	-	nm
Photosensitivity	S	$\lambda = \lambda_p$	0.6	0.68	-	A/W
Dark current	ID	VR=10 V	-	-	5.0	nA
Temperature coefficient of ID	ΔTID	VR=10 V	-	1.15	-	times/°C
Cutoff frequency	fc	VR=10 V, RL=50 Ω $\lambda=830$ nm, -3 dB	-	10	-	MHz
Terminal capacitance	Ct	VR=10 V, f=10 kHz	-	9	13	pF
Noise equivalent power	NEP	VR=10 V, $\lambda = \lambda_p$	-	1.6×10^{-14}	-	W/Hz ^{1/2}


Spectral response







Dark current vs. reverse voltage (per element)



Terminal capacitance vs. reverse voltage (per element)



Dimensional outline (unit: mm)




- ① NC
- ② Anode A
- ③ Cathode F
- ④ Anode F
- ⑤ Anode E
- ⑥ Cathode E
- ⑦ Anode D
- ⑧ Cathode D
- ⑨ Cathode C
- ⑩ Anode C
- ⑪ Anode B
- ⑫ Cathode B
- ⑬ Cathode A
- ⑭ Ground plane

Tolerance unless otherwise noted: ± 0.15
 Note: NTH: for position adjustment during mounting

KMPDA0622EA

Recommended land pattern (unit: mm)



1. Solder all terminals.
2. Do not make the land area larger than necessary.
3. It is preferable that the land sizes be about equal.


KMPDC0785EA

Standard packing specifications

- Reel (conforms to JEITA ET-7200)

Outer diameter	Hub diameter	Tape width	Material	Electrostatic characteristics
330 mm	100 mm	24 mm	PS	Conductive


- Embossed tape (unit: mm, material: PS, conductive)



KMPDC0788EA

- Packing quantity
1000 pcs/reel
- Packing state
Reel and desiccant in moisture-proof packaging (vacuum-sealed)

Recommended reflow soldering conditions



- After unpacking, keep it in an environment at 5 to 30 °C and a humidity of 60% or less, and perform soldering within 168 hours.
- The effect that the product receives during reflow soldering varies depending on the circuit board and reflow oven that are used.
- When you set reflow soldering conditions, check that problems do not occur in the product by testing out the conditions in advance.

KPINB0385EB

Related information

www.hamamatsu.com/sp/ssd/doc_en.html

■ Precautions

- Disclaimer
- Surface mount type products

■ Technical information

- Si photodiodes / Application circuit examples

Information described in this material is current as of January 2021.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.

HAMAMATSU

www.hamamatsu.com

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81)53-434-3311, Fax: (81)53-434-5184

U.S.A.: Hamamatsu Corporation: 360 Foothill Road, Bridgewater, N.J. 08807, U.S.A., Telephone: (1)908-231-0960, Fax: (1)908-231-1218, E-mail: usa@hamamatsu.com

Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, D-82211 Herrsching am Ammersee, Germany, Telephone: (49)8152-375-0, Fax: (49)8152-265-8, E-mail: info@hamamatsu.de

France: Hamamatsu Photonics France S.A.R.L.: 19, Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy Cedex, France, Telephone: (33)1 69 53 71 00, Fax: (33)1 69 53 71 10, E-mail: infos@hamamatsu.fr

United Kingdom: Hamamatsu Photonics UK Limited: 2 Howard Court, 10 Tewin Road, Welwyn Garden City, Hertfordshire AL7 1BW, UK, Telephone: (44)1707-294888, Fax: (44)1707-325777, E-mail: info@hamamatsu.co.uk

North Europe: Hamamatsu Photonics Norden AB: Torshamnsgatan 35 16440 Kista, Sweden, Telephone: (46)8-509 031 00, Fax: (46)8-509 031 01, E-mail: info@hamamatsu.se

Italy: Hamamatsu Photonics Italia S.r.l.: Strada della Moia, 1 int. 6, 20020 Arese (Milano), Italy, Telephone: (39)02-93 58 17 33, Fax: (39)02-93 58 17 41, E-mail: info@hamamatsu.it

China: Hamamatsu Photonics (China) Co., Ltd.: 1201 Tower B, Jiaming Center, 27 Dongsanhuan Bellu, Chaoyang District, 100020 Beijing, P.R.China, Telephone: (86)10-6586-6006, Fax: (86)10-6586-2866, E-mail: hpc@hamamatsu.com.cn

Taiwan: Hamamatsu Photonics Taiwan Co., Ltd.: 8F-3, No. 158, Section2, Gongdao 5th Road, East District, Hsinchu, 300, Taiwan R.O.C. Telephone: (886)3-659-0080, Fax: (886)3-659-0081, E-mail: info@hamamatsu.com.tw