

C9004

## Driver circuit for 16-element photodiode array

### Features

- High precision and high-speed measurement by simultaneous 16-channel readout
- Assembled with pulse generator (8-step adjustable oscillatory frequency)  
CLK, START, A/D conversion Trig and  $\overline{\text{EOS}}$  pulse output
- Choice of gain (conversion impedance):  $1 \times 10^6$  or  $1 \times 10^7$  (V/A)
- Hamamatsu S4111-16 series, S11212 series photodiode arrays are directly mountable on board.
- Single power supply operation: +12 V

### Applications

- Performance evaluation of Hamamatsu S4111-16 series, S11212 series photodiode arrays
- Position measurement
- Displacement measurement

### Absolute maximum ratings (Ta=25 °C unless otherwise noted)

Parameter	Symbol	Value	Unit
Supply voltage	Vcc max.	+18	V
Input current	Iin max.	$+6.7 \times 10^{-5}$	A
Operating temperature*1	Topr	0 to +50	°C
Storage temperature*1	Tstg	-20 to +80	°C

\*1: No dew condensation

When there is a temperature difference between a product and the surrounding area in high humidity environment, dew condensation may occur on the product surface. Dew condensation on the product may cause deterioration in characteristics and reliability.

Note: Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.

**Electrical and optical characteristics (Ta=25 °C)**

Parameter	Symbol	Condition	Min.	Typ.	Max.	Unit
Input current range	I <sub>in</sub>	T <sub>z</sub> =1 × 10 <sup>6</sup>	-	-	1 × 10 <sup>-5</sup>	A
		T <sub>z</sub> =1 × 10 <sup>7</sup>	-	-	1 × 10 <sup>-6</sup>	A
Conversion impedance*2	T <sub>z</sub>		1 × 10 <sup>6</sup>	-	1 × 10 <sup>7</sup>	V/A
Output offset voltage	V <sub>os</sub>	T <sub>z</sub> =1 × 10 <sup>6</sup> (set up prior to shipping)	-	0.025	-	V
		T <sub>z</sub> =1 × 10 <sup>7</sup> *3	-	0.25	-	V
Output amplitude voltage	V <sub>o</sub>	T <sub>z</sub> =1 × 10 <sup>6</sup> , R <sub>L</sub> =1 kΩ	0	-	+10	V
		T <sub>z</sub> =1 × 10 <sup>7</sup> , R <sub>L</sub> =1 kΩ	0	-	+10	V
Output noise voltage	e <sub>np-p</sub>	T <sub>z</sub> =1 × 10 <sup>6</sup> (full bandwidth)	-	5	-	mVp-p
		T <sub>z</sub> =1 × 10 <sup>7</sup> (full bandwidth)	-	10	-	mVp-p
Rise time	tr	T <sub>z</sub> =1 × 10 <sup>6</sup> , R <sub>L</sub> =1 kΩ	-	5.6	-	μs
		T <sub>z</sub> =1 × 10 <sup>7</sup> , R <sub>L</sub> =1 kΩ	-	5.6	-	μs
Capacitive load	CL		-	-	100	pF
Oscillatory frequency (OUT)*4	CLK		1.5625	-	200	kHz
Start pulse width (OUT)*4	-		5	-	640	μs
Output format*5	-		TTL			-
Current consumption	I <sub>cc</sub>		-	200	250	mA


\*2: Conversion impedance can be changed with the switch on the circuit board.

\*3: The variable resistor V<sub>R</sub> on the circuit board must be used for making offset adjustments.

\*4: Adjustable in 8 steps by using the BCD rotary switch on the circuit board


\*5: CLK, START, Trig and EOS pulse output format

**Block diagram**




KACCC0181EB


**Timing chart**



**Dimensional outline (unit: mm)**



### Connection example



KACCC0813EA

### Accessories

- Instruction manual
- AC adapter
- Flat cable (200 mm) with I/O connector receptacle

### Related information

[www.hamamatsu.com/sp/ssd/doc\\_en.html](http://www.hamamatsu.com/sp/ssd/doc_en.html)

#### Precautions

- Disclaimer

Information described in this material is current as of July 2016.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.

# HAMAMATSU

[www.hamamatsu.com](http://www.hamamatsu.com)

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81) 53-434-3311, Fax: (81) 53-434-5184

U.S.A.: Hamamatsu Corporation: 360 Foothill Road, Bridgewater, N.J. 08807, U.S.A., Telephone: (1) 908-231-0960, Fax: (1) 908-231-1218

Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, D-82211 Herrsching am Ammersee, Germany, Telephone: (49) 8152-375-0, Fax: (49) 8152-265-8

France: Hamamatsu Photonics France S.A.R.L.: 19, Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy Cedex, France, Telephone: 33-(1) 69 53 71 00, Fax: 33-(1) 69 53 71 10

United Kingdom: Hamamatsu Photonics UK Limited: 2 Howard Court, 10 Tewin Road, Welwyn Garden City, Hertfordshire AL7 1BW, United Kingdom, Telephone: (44) 1707-294888, Fax: (44) 1707-325777

North Europe: Hamamatsu Photonics Norden AB: Torshamnsgatan 35 16440 Kista, Sweden, Telephone: (46) 8-509-031-00, Fax: (46) 8-509-031-01

Italy: Hamamatsu Photonics Italia S.r.l.: Strada della Moia, 1 int. 6, 20020 Arese (Milano), Italy, Telephone: (39) 02-93581733, Fax: (39) 02-93581741

China: Hamamatsu Photonics (China) Co., Ltd.: B1201, Jiaming Center, No.27 Dongsanhuan Beilu, Chaoyang District, Beijing 100020, China, Telephone: (86) 10-6586-6006, Fax: (86) 10-6586-2866