



C7557-01

## For control of multichannel detector head and data acquisition

The C7557-01 is specifically designed for basic control in multichannel photometry. When connected to Hamamatsu multichannel detector head and a PC, the C7557-01 allows easy control of the detector head and data acquisition by using dedicated software that comes with the unit.

The C7557-01 supports main models of Hamamatsu multichannel detector heads designed to use CCD/InGaAs image sensors. The C7557-01 provides various useful functions (see P.2) that efficiently collect sample data during basic operation.

The C7557-01 controller includes a driver/amplifier circuit for operating a multichannel detector head, a power supply circuit, a temperature stabilizer circuit, an A/D conversion circuit that converts analog signals from the detector head into digital signals, and a data interface.

The software supplied with the C7557-01 allows easy control of the multichannel detector head and data acquisition through the USB interface. This software runs on Microsoft® Windows®\*1, by simple operation from the menu neatly displayed on the screen. This software is available with different kinds of DLL\*2 to help you develop your own software programs.


### Features

- Easy to control multichannel detector head and data acquisition
- Supports main models of Hamamatsu multichannel detector heads (CCD, InGaAs)
- Software with different kind of DLL is supplied with the C7557-01
- Compact configuration

### Applications

- Control of multichannel detector head and data acquisition

### Connection example



Note: Shutter, etc. are not available.

KACCC0402EF

\*1: Microsoft, Windows and Visual C++ are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.

\*2: DLL is one of useful functions the Windows. It is a library that can freely start up from application software or execute function procedure. Software development can be made easier with DLL. To use DLL, see the operation manual that comes with the unit. The development environment should be Microsoft® Visual C++®\*1 2015 or later, or LabVIEW™\*3 2017 SP1 (LabVIEW 2022 Q3 or later for Windows 11) or later.

\*3: LabVIEW is a trademark of National Instruments, Inc.

**Functions**

Parameter	Specification
Data transfer	Transfers data stored in memory to computer.
Exposure time setting	1 ms to 65535 ms (1 ms steps) Minimum exposure time depends on sensor detection level.
External sync signal input	BNC connector input
Trigger mode	Internal sync, external sync
Trigger polarity	Trigger polarity selectable for external sync
Shutter timing pulse output	Outputs timing signal for operating external shutter or external light source via BNC connector. Pulse width, delay and polarity settings are possible.
Video signal output	Outputs video signal sent from head, via BNC connector
Video sync signal output	Outputs sync signal used to observe video signal output with external device such as oscilloscope, via BNC connector
Amplifier gain	1/2, 1, 2, 5, 10, 20, 50, 100*4
Image sensor and detector head combination	Compatible with each multichannel detector head Refer to "Selection guide for image sensor and detector head combination"
Detector cooling control	Cooling start and stop
Detector cooling temperature readout	Converts analog temperature data from detector into digital signal, and transfers it to computer. (10-bit A/D conversion)

\*4: Depending on the drive conditions, normal output may not be obtained if the amplifier gain is set too high. In this case, lower the amplifier gain.

**Specifications**

■ A/D converter

Parameter	InGaAs linear image sensor	
	CCD area image sensor	
A/D converter	16 bits	12 bits      16 bits
Conversion speed	4 μs/ch	2 μs/ch      8 μs/ch
Input range	0 to 10 V	-10 to +10 V
Input method	Differential input	
Nonlinear linearity	0.1%FS	
A/D conversion signal	External input	

■ Controller

Parameter	Specification
Clock	20 MHz
Memory	4 MB (1024 ch × 2048 lines)
Interface	USB 2.0

■ Equipment

Parameter	Specification
Interface	USB 2.0 Type B connector
Power supply	AC100 to 240 V ± 10%, 50 to 60 Hz
Power consumption	50 V · A typ.
Dimension (W × H × D)	92 × 150 × 226 mm
Operating temperature	0 to 40 °C
Storage temperature	-10 to 50 °C
Weight	Approx. 2.5 kg


■ Software

Parameter	Specification
Compatible OS	Windows 10 (32-bit, 64-bit), Windows 11

- Prepare a BNC cable in the following cases:
  - Measurements by external sync
  - Controlling an external shutter or external light source
  - Measuring the video signal

**■ Operation method**

1. Make connections as indicated in ① to ⑤.
  - ① LINE                      Connect to the power cable.
  - ② USB                        Connect to a computer through the USB cable.
  - ③ TE CONTROL I/O        Connect to the "TE CONTROL I/O" terminal on the detector head.
  - ④ SIGNAL I/O              Connect to the "I/O SIGNAL" terminal on the detector head.
  - ⑤ GND                        When a 2-pin AC plug is used with the power cable, use this GND connector to ground the unit.
2. When all the connections are complete, turn on the power to the C7557-01.
3. Install the MCD USB driver and software. (For details on the MCD USB driver and software, refer to the operation manual supplied in the package.)




KACCC0403EA

## Software functions

From the main screen menu, you can easily set operating conditions for the multichannel detector head and data acquisition parameters. The measurement screen displayed with this software shows the image sensor channel along the horizontal axis and the output count along the vertical axis. The main screen menu also allows to select the desired operation mode: line binning or area scanning (for CCD image sensors) or line scanning (for InGaAs linear image sensors).

The parameters that can be set on the main screen are as follows:


- Exposure time
- Amplifier gain
- Cooling control
- Number of integrations
- Dark correction
- Type of measurement data
- Start or end of measurement
- Detector head status
- Trigger mode
- Trigger polarity
- Shutter timing pulse width
- Shutter timing pulse delay
- Shutter timing pulse polarity



▣ Selection guide for image sensor and detector head combination

Suitable multichannel detector head	Image sensor				
Type no.	Type no.	Number of effective pixel	Image size [mm (H) × mm (V)]	Types of sensor	
C7020	S9970-0906	512 × 60	12.288 × 1.440	Front-illuminated CCD area image sensor	
	S9970-1006	1024 × 60	24.576 × 1.440		
	S9970-1007	1024 × 124	24.576 × 2.976		
	S9970-1008	1024 × 252	24.576 × 6.048		
C7021	S9971-0906	512 × 60	12.288 × 1.440		
	S9971-1006	1024 × 60	24.576 × 1.440		
	S9971-1007	1024 × 124	24.576 × 2.976		
C7025-02	S9973-1008	1024 × 252	24.576 × 6.048		
C7040	S7030-0906	512 × 58	12.288 × 1.392		Back-thinned CCD area image sensor
	S7030-0907	512 × 122	12.288 × 2.928		
	S7030-1006	1024 × 58	24.576 × 1.392		
	S7030-1007	1024 × 122	24.576 × 2.928		
	S16000-1007	1024 × 122	24.576 × 2.928		
C7041	S7031-0906S	512 × 58	12.288 × 1.392		
	S7031-0907S	512 × 122	12.288 × 2.928		
	S7031-1006S	1024 × 58	24.576 × 1.392		
	S7031-1007S	1024 × 122	24.576 × 2.928		
	S16001-1007S	1024 × 122	24.576 × 2.928		
C10150-01	S10140-1107-01	2048 × 122	24.576 × 1.464		
	S10140-1108-01	2048 × 250	24.576 × 3.000		
	S10140-1109-01	2048 × 506	24.576 × 6.072		
C10151-01	S10141-1107S-01	2048 × 122	24.576 × 1.464		
	S10141-1108S-01	2048 × 250	24.576 × 3.000		
	S10141-1109S-01	2048 × 506	24.576 × 6.072		
C8061-01	G9201-256SB	256	12.8 × 0.25	InGaAs linear image sensor	
	G9202-512SB	512	12.8 × 0.25		
	G9203-256SA	256	12.8 × 0.50		
	G9204-512SA	512	12.8 × 0.50		
	G9211-256SB	256	12.8 × 0.25		
	G9212-512SB	512	12.8 × 0.25		
	G9213-256SA	256	12.8 × 0.50		
	G9214-512SA	512	12.8 × 0.50		
C8062-01	G9205-256WB	256	12.8 × 0.25		
	G9205-512WB	512	12.8 × 0.25		
	G9206-02B	256	12.8 × 0.25		
	G9206-256WB	256	12.8 × 0.25		
	G9206-512WB	512	12.8 × 0.25		
	G9207-256WB	256	12.8 × 0.25		
	G9208-256WB	256	12.8 × 0.25		
	G9208-512WB	512	12.8 × 0.25		

**Dimensional outline (unit: mm)**



KACCA0237EA

**Accessories**

- Spare fuse (2.5 A)\*5 1
- AC cable 1
- USB cable 1
- Detector head connection cables 2  
(for "SIGNAL I/O" and "TE CONTROL I/O" terminal of multichannel detector head)
- CD-R (MCD USB driver, Software, Operation manual) 1

\*5: Contained in the holder just above the AC cable connector on the C7557-01 rear panel.

**Related information**

[www.hamamatsu.com/sp/ssd/doc\\_en.html](http://www.hamamatsu.com/sp/ssd/doc_en.html)

- Precautions
- Disclaimer

Information described in this material is current as of September 2025.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.

**HAMAMATSU**

[www.hamamatsu.com](http://www.hamamatsu.com)

Optical Semiconductor Sales, HAMAMATSU PHOTONICS K.K.

1126-1 Ichino-cho, Chuo-ku, Hamamatsu City, Shizuoka Pref., 435-8558 Japan, Telephone: (81)53-434-3311, Fax: (81)53-434-5184

U.S.A.: HAMAMATSU CORPORATION: 360 Foothill Road, Bridgewater, NJ 08807, U.S.A., Telephone: (1)908 231 0960, Fax: (1)908 231 1218

Germany: HAMAMATSU PHOTONICS DEUTSCHLAND GMBH: Arzbergerstr. 10, 82211 Herrsching am Ammersee, Germany, Telephone: (49)8152 375 0, Fax: (49)8152 265 8 E mail: info@hamamatsu.de

France: HAMAMATSU PHOTONICS FRANCE S.A.R.L.: 19 Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy Cedex, France, Telephone: (33)1 69 53 71 00, Fax: (33)1 69 53 71 10 E mail: info@hamamatsu.fr

United Kingdom: HAMAMATSU PHOTONICS UK LIMITED: 2 Howard Court, 10 Tewin Road, Welwyn Garden City, Hertfordshire, AL7 1BW, UK, Telephone: (44)1707 294888, Fax: (44)1707 325777 E mail: info@hamamatsu.co.uk

North Europe: HAMAMATSU PHOTONICS NORDEN AB: Torshamnsgatan 35, 16440 Kista, Sweden, Telephone: (46)8 509 031 00, Fax: (46)8 509 031 01 E mail: info@hamamatsu.se

Italy: HAMAMATSU PHOTONICS ITALIA S.R.L.: Strada della Moia, 1 int. 6 20044 Arese (Milano), Italy, Telephone: (39)02 93 58 17 33, Fax: (39)02 93 58 17 41 E mail: info@hamamatsu.it

China: HAMAMATSU PHOTONICS (CHINA) CO., LTD.: 1201, Tower B, Jianning Center, 27 Dongsanhuan Beilu, Chaoyang District, 100020 Beijing, P.R. China, Telephone: (86)10 6586 6006, Fax: (86)10 6586 2866 E mail: hpc@hamamatsu.com.cn

Taiwan: HAMAMATSU PHOTONICS TAIWAN CO., LTD.: 13F 1, No.101, Section 2, Gongdao 5th Road, East Dist., Hsinchu City, 300046, Taiwan(R.O.C) Telephone: (886)3 659 0080, Fax: (886)3 659 0081 E mail: info@hamamatsu.com.tw

Korea: HAMAMATSU PHOTONICS KOREA CO., LTD.: A 912, 167, Songpa daero, Seoul, 05855, Korea, Telephone: (82)2 2054 8202, Fax: (82)2 2054 8207 E mail: sales@hpkr.co.kr